

Overflow Exception

After launching Modelsim change **Resolution** from “ns” to “ps” in the Start ModelSim 6.3-6.5 Dialogue Box.

Video Memory configuration

The video memory in the Display_IF component has 8192 words. The size of each word is 15 bits.